ARBRE TR.BMW X3 E86

New part

FTTATT

3599771001226



TECHNICAL DATA

Length [mm]	**718 mm**

PICTURES





Before installation, compare the part received with the original part to ensure that the correct part number has been selected and can be installed on the vehicle. Failure to follow those, or the manufacturer, instructions will void the warranty.

BMW		
3 Series (98-06) (E46) - 325 xi	192 ch	09.2000 > 02.2005
3 Series (98-06) (E46) - 330 xi	231 ch	06.2000 > 02.2005
3 Series (98-06) (E46) - 330 xd	184 ch	01.2000 > 02.2003
	204 ch	09.2002 > 12.2004
3 Series (98-06) Coupe (E46) - 330 xi	231 ch	06.2000 > 07.2006
3 Series (98-06) Break/Touring (E46) - 325 xi	192 ch	09.2000 > 02.2005
3 Series (98-06) Break/Touring (E46) - 330 xi	231 ch	06.2000 > 02.2005
3 Series (98-06) Break/Touring (E46) - 330 xd	184 ch	01.2000 > 03.2003
	204 ch	08.2002 > 05.2005
X3 (03-10) (E83) - 2.5 i	192 ch	03.2004 > 07.2006
X3 (03-10) (E83) - 2.5 si xDrive	211 ch	08.2006 > 08.2008
X3 (03-10) (E83) - 2.5 si	218 ch	08.2006 > 08.2008
X3 (03-10) (E83) - xDrive 25 i	218 ch	09.2008 > 08.2010
X3 (03-10) (E83) - 3.0 i xDrive	231 ch	09.2003 > 07.2006
X3 (03-10) (E83) - 3.0 si	272 ch	08.2006 > 08.2008
X3 (03-10) (E83) - xDrive 30 i	272 ch	09.2008 > 08.2010
X3 (03-10) (E83) - xDrive 18 d	136 ch	04.2009 > 12.2011
	143 ch	09.2008 > 12.2011
X3 (03-10) (E83) - 2.0 d	150 ch	09.2004 > 08.2007
X3 (03-10) (E83) - 2.0 sd	177 ch	09.2007 > 08.2008
X3 (03-10) (E83) - xDrive 20 d	163 ch	09.2008 > 08.2010
	177 ch	09.2008 > 08.2010
X3 (03-10) (E83) - 3.0 d	204 ch	01.2004 > 08.2005
	211 ch	09.2005 > 08.2008
X3 (03-10) (E83) - xDrive 30 d	211 ch	09.2008 > 08.2010
X3 (03-10) (E83) - 3.0 d	218 ch	**09.2005 > 12.2005**
X3 (03-10) (E83) - xDrive 30 d	218 ch	09.2008 > 08.2010
X3 (03-10) (E83) - 3.0 sd	286 ch	09.2006 > 08.2008
X3 (03-10) (E83) - xDrive 35 d	286 ch	09.2008 > 08.2011