POMP DIR FORD SCORPIO/SIE

Remanufactured

Core code : 70

FCDADP

3599771439463



TECHNICAL DATA

Operating Mode	**hydraulic**
Info complémentaire	**with reservoir**
for steering manufacturer	**SAGINAW**
Rotation Direction	**Clockwise rotation**
Overall Length [mm]	**96 mm**
Pressure Line Connection Thread Size	**Ø10mm**
Backflow Connector Thread Size	**F16x150**
Pulley fitting	**Triangular baseplate**
Number of rear fixation points	**1**

PICTURES











Before installation, compare the part received with the original part to ensure that the correct part number has been selected and can be installed on the vehicle. Failure to follow those, or the manufacturer, instructions will void the warranty.

FORD		
GRANADA (72-77) (GGTL, GGFL) - 2.3	108 ch	01.1972 > 02.1976
	108 ch	01.1975 > 08.1977
GRANADA (72-77) Coupe (GGCL) - 2.3	108 ch	01.1972 > 02.1976
GRANADA (72-77) Break (GGNL) - 2.3	108 ch	01.1972 > 02.1976
GRANADA (77-85) (GU) - 2.3	107 ch	08.1977 > 06.1979
	112 ch	06.1981 > 08.1985
	114 ch	06.1979 > 08.1985
GRANADA (77-85) (GU) - 2.8	132 ch	06.1981 > 08.1985
	135 ch	08.1977 > 08.1985
GRANADA (77-85) (GU) - 2.8 i	147 ch	08.1977 > 08.1985
	150 ch	10.1982 > 08.1985
	160 ch	08.1977 > 08.1981
GRANADA (77-85) Break (GNU) - 2.3	107 ch	08.1977 > 06.1979
	111 ch	06.1981 > 06.1985
	114 ch	06.1979 > 08.1985
GRANADA (77-85) Break (GNU) - 2.8	132 ch	06.1981 > 08.1985
	135 ch	08.1977 > 08.1985
GRANADA (77-85) Break (GNU) - 2.8 i	147 ch	08.1977 > 08.1985
	150 ch	10.1982 > 08.1985
	160 ch	08.1977 > 08.1981
SCORPIO (86-94) (GAE, GGE) - 2.4 i	125 ch	10.1988 > 02.1992
SCORPIO (86-94) (GAE, GGE) - 2.4 i Cat	125 ch	10.1988 > 09.1994
SCORPIO (86-94) (GAE, GGE) - 2.4 i	130 ch	09.1986 > 09.1988
SCORPIO (86-94) (GAE, GGE) - 2.8 i	150 ch	04.1985 > 11.1986
SCORPIO (86-94) (GAE, GGE) - 2.8 i 4x4	150 ch	10.1985 > 11.1986
SCORPIO (86-94) (GAE, GGE) - 2.9 i	145 ch	09.1986 > 09.1994
SCORPIO (86-94) (GAE, GGE) - 2.9 i Cat	145 ch	10.1987 > 09.1994
SCORPIO (86-94) (GAE, GGE) - 2.9 i 4x4	145 ch	05.1988 > 02.1993
SCORPIO (86-94) (GAE, GGE) - 2.9 i	150 ch	09.1986 > 09.1994
SCORPIO (86-94) (GAE, GGE) - 2.9 i 4x4	150 ch	09.1986 > 09.1994
SCORPIO (86-94) (GAE, GGE) - 2.9 i 24V	195 ch	04.1991 > 09.1994
SCORPIO (86-94) 3 volumes (GGE) - 2.4 i	125 ch	10.1988 > 10.1994
SCORPIO (86-94) 3 volumes (GGE) - 2.9 i	145 ch	09.1986 > 12.1994
SCORPIO (86-94) 3 volumes (GGE) - 2.9 i 4x4	145 ch	12.1989 > 10.1994
SCORPIO (86-94) 3 volumes (GGE) - 2.9 i 24V	195 ch	04.1991 > 09.1994
SCORPIO (86-94) Break (GGE) - 2.4 i	125 ch	09.1991 > 09.1994
SCORPIO (86-94) Break (GGE) - 2.9 i	145 ch	09.1991 > 09.1994
SCORPIO (86-94) Break (GGE) - 2.9 i 4x4	145 ch	05.1988 > 02.1993
SCORPIO (86-94) Break (GGE) - 2.9 24V	195 ch	08.1993 > 09.1994
SIERRA (82-86) 3/5 portes (GBC) - 1.8	90 ch	10.1984 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.3	114 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.8 XR4i	143 ch	08.1982 > 12.1986
	146 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.8 i XR 4x4	146 ch	09.1983 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.8 XR4i	150 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.8 XR 4x4	150 ch	02.1985 > 12.1986
SIERRA (82-86) Break (BNC) - 1.8	90 ch	10.1984 > 12.1986
SIERRA (82-86) Break (BNC) - 2.3	114 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 2.8 XR4i	143 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 2.8 i 4x4	143 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 2.8 XR4i	146 ch	08.1982 > 12.1986

FORD		
SIERRA (82-86) Break (BNC) - 2.8 i 4x4	146 ch	08.1982 > 12.1986
SIERRA (87-93) (GBG, GB4) - 1.8	87 ch	05.1988 > 02.1993
	80 ch	10.1987 > 09.1989
	90 ch	01.1987 > 05.1988
SIERRA (87-93) (GBG, GB4) - 2.9 i	145 ch	08.1988 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.9 4x4	145 ch	08.1988 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.9 i	150 ch	08.1988 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.9 4x4	150 ch	08.1988 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 1.8	80 ch	10.1987 > 05.1988
	87 ch	05.1988 > 02.1993
	90 ch	01.1987 > 05.1988
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.8 i	143 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.8 i XR 4x4	146 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.8	150 ch	03.1987 > 09.1989
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.8 i XR 4x4	150 ch	01.1987 > 08.1988
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.9 i	145 ch	08.1988 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.9 i XR 4x4	145 ch	08.1988 > 02.1993
	150 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 1.8	80 ch	10.1987 > 05.1988
	87 ch	05.1988 > 02.1993
	90 ch	01.1987 > 05.1988
SIERRA (87-93) Break (BNG) - 2.8 i	143 ch	01.1987 > 02.1993
	146 ch	01.1987 > 02.1993
SIERRA (87-93) Break (BNG) - 2.8 4x4	150 ch	01.1987 > 08.1988
SIERRA (87-93) Break (BNG) - 2.9	145 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 2.9 4x4	145 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 2.9 i	150 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 2.9 4x4	150 ch	08.1988 > 02.1993